

APPLICATOR PARTS LIST

TYPE THRU SPLICE  
END FEED INS. SUPPORT

AMP INCORPORATED  
HARRISBURG, PENNA.

| NO. | DESCRIPTION             | REQ. | PART NO.   | NO.  | DESCRIPTION        | REQ.    | PART NO.  | NO.       | TO APPLY TERMINAL | TERMINALS           |
|-----|-------------------------|------|------------|------|--------------------|---------|-----------|-----------|-------------------|---------------------|
| 1   | WIRE CRIMPER            | 1    | 456411-3   | 42   |                    |         |           |           |                   | 41197               |
| 2   | INS. CRIMPER            | 1    | 453944-3   | 43   | SPRING, SLIDE      | 1       | 2-24017-7 |           | CRIMPING DATA     | 42627               |
| 3   | ANVIL                   | 1    | 464359-1   | 44   | FEED PLATE RET.    | 1       | 37299B    |           | WIRE SIZE         |                     |
| 4   | ANVIL SPACER            |      |            | 45   |                    |         |           |           | CRIMP HEIGHT      |                     |
| 5   | SHEAR BLADE             | 1    | 376894     | 46   |                    |         |           |           |                   |                     |
| 6   | FEED PLATE              | 1    | 376905     | 47   |                    |         |           |           |                   |                     |
| 7   | SHEAR BLADE SPACER      |      |            | 48   |                    |         |           |           |                   |                     |
| 8   | FRONT SHEAR PLATE       |      |            | 49   |                    |         |           |           |                   |                     |
| 9   | REAR ANVIL SPACER PLT.  |      |            | 50   |                    |         |           |           |                   |                     |
| 10  | FRONT ANVIL SPACER PLT. |      |            | 51   |                    |         |           |           | CRIMP             |                     |
| 11  | TOOL SPACER             |      |            | 52   |                    |         |           |           | WIRE              | .140                |
| 12  | CRIMP SPACER            | 1    | 370592     | 53   |                    |         |           |           | INSUL.            | .180                |
| 13  | FRONT STRIP GUIDE       |      |            | 54   |                    |         |           |           | SLEEVED           |                     |
| 14  | REAR STRIP GUIDE        |      |            | 55   | SCREW, SQ HD       | 1       | 21077-7   |           | INSULATION RANGE  | 3200-8200           |
| 15  | RAM                     | 1    | 471057     | 56   | NUT, JAM           | 1       | 22202-1   |           | EXPLODED VIEW     |                     |
| 16  | TOOL HOLDER             |      |            | 57   |                    |         |           |           | REMARKS           | A-6010-1 & A-6010-2 |
| 17  | ADJ. CRIMP MOUNT        |      |            | 58   |                    |         |           |           |                   | TOP TOOL MOUNTING   |
| 18  | ADJ. BLOCK              |      |            | 59   |                    |         |           |           |                   | 2, 12 & 1           |
| 19  | APPLICATOR MOUNT ASSY.  | 1    | 473933     | 60   |                    |         |           |           |                   |                     |
| 20  | BASE PLATE              |      |            | 61   |                    |         |           |           |                   |                     |
| 21  | BASE BLOCK              |      |            | 62   |                    |         |           |           |                   |                     |
| 22  | STRIP GUIDE PLATE       |      |            | 63   |                    |         |           |           |                   |                     |
| 23  | ANVIL HOLDER            | 1    | 385941     | 64   |                    |         |           |           |                   |                     |
| 24  | AUX. ANVIL HOLDER       | 1    | 378975     | 65   | TENSION ADJ. PLATE | 1       | 374 999   |           |                   |                     |
| 25  | STRIPPER                | 1    | 811058-1   | 66   | MISCELLANEOUS      |         |           |           |                   |                     |
| 26  | STRIPPER MOUNT          |      |            | 67   | LUBRICATOR ASS'Y   |         | 465184-2  |           |                   |                     |
| 27  | SPACER, STRIPPER        | 2    | 377027     | 68   | TERMINAL LUB.      |         | 561230-3  |           |                   |                     |
| 28  | STRIPPER MOUNT BRACKET  |      |            | 69   |                    |         |           |           |                   |                     |
| 29  | STRIPPER BUSHING        |      |            | 70   |                    |         |           |           |                   |                     |
| 30  | STOCK DRAG              | 1    | 372990     | 71   | SCREW, DRIVE       | 3       | 21077-6   |           |                   |                     |
| 31  | STOCK DRAG NUT          | 1    | 21022-4    | 72   | SERIAL NO TAG      | 1       | 4523734   |           |                   |                     |
| 32  | STOCK DRAG STUD         | 1    | 21015-8    | REV. | REVISION RECORD    | DATE    | BY        | ECN       |                   |                     |
| 33  | STOCK DRAG SPRING       | 1    | 23346-7    | D    | REINSTATE OBS DWG  | 4-21-87 | JR        | OF R-7465 |                   |                     |
| 34  | STOCK DRAG ADJ. SCREW   | 2    | 372997     |      |                    |         |           |           |                   |                     |
| 35  | FEED FINGER HOLDER      |      |            |      |                    |         |           |           | SERIAL NO.        | DATE SHIPPED        |
| 36  | FEED FINGER             | 1    | 811432-1   |      |                    |         |           |           |                   | DESIGNED            |
| 37  | FEED FINGER TIP         |      |            |      |                    |         |           |           |                   | JEB 4-21-87         |
| 38  | FEED FINGER SPACER      |      |            |      |                    |         |           |           |                   | CHE'S               |
| 39  | BASE CASTING            | 1    | 570238     |      |                    |         |           |           |                   | 42489               |
| 40  | GUARD ASSY              | 1    | 1-462582-2 |      |                    |         |           |           |                   | APPRO.              |
| 41  |                         |      |            |      |                    |         |           |           |                   | 8/11/87             |

■ DENOTES WEARING PARTS  
RECOMMEND PURCHASE REPLACEMENT

THIS APPLICATOR IS TO BE USED ON  
AMP-O-ELECTRIC **1-471273-3**  
~~MECH FEED~~ **MECH FEED**

DIST. 4

APPLICATOR NUMBER **D** REV. **6720844** SHEET **1** OF **1**

CUSTOMER NAME AND ADDRESS